





Verizon Ordering Guide

990DSL CopperPro


	SSI/PID # 700-254-464 933275	VPN V-MODEL-A	Description 990DSL CopperPro – Basic POTS Model + TDR Loop test and fault locating set with following functions: digital multimeter functions, opens, RFL, VF noise and loss meter, leakage, tone generator, ANI and CID verification, dial set, dial-up test macros. <i>This configuration includes the TDR option.</i> Application: Installation and maintenance of POTS services. Cable repair and maintenance. Not suitable for ADSL or special services applications.
	SSI/PID # 700-254-465 933276	VPN V-MODEL-B	Description 990DSL CopperPro – Basic POTS Model + Wideband Loop test and fault locating set with following functions: digital multimeter functions, opens, RFL, VF noise and loss meter, leakage, tone generator, ANI and CID verification, dial set, dial-up test macros. <i>This configuration includes basic wideband source and measurement functions.</i> Application: Installation and maintenance of POTS services. Cable repair and maintenance. Basic acceptance testing for digital and special services circuits. TDR is not included.
	SSI/PID # 700-254-466 933277	VPN V-MODEL-C	Description 990DSL CopperPro – Basic POTS Model + TDR + Wideband Loop test and fault locating set with following functions: digital multimeter functions, opens, RFL, VF noise and loss meter, leakage, tone generator, ANI and CID verification, dial set, dial-up test macros. <i>This configuration includes basic wideband source and measurement functions and TDR</i> Application: Installation and maintenance of POTS services. Cable repair and maintenance. Basic acceptance testing for digital and special services circuits.
	SSI/PID # 700-254-467 933278	VPN V-MODEL-CX	Description 990DSL CopperPro – Basic POTS Model + Wideband + TDR + DSL Qualification and Analysis functions (Spectral Analysis). Loop test and fault locating set with following functions: digital multimeter functions, opens, RFL, VF noise and loss meter, leakage, tone generator, ANI and CID verification, dial set, dial-up test macros. <i>This configuration includes full wideband source and measurement, spectral analysis and automated xDSL qualification functions, and TDR</i> Application: Installation and maintenance of POTS services. Cable repair and maintenance. Advanced acceptance and prequalification testing and troubleshooting for HDSLx, ADSL and other digital and special services circuits.




Far End Terminating Device

	SSI/PID #	VPN	Description
	11018277	TN2100/VZ	Enhanced Terminator Remote Termination Device Small, battery operated, remote device for terminated testing applications, including HDSL prequalification. Includes high-speed composite tone generation. Controlled by CopperPro unit.
	11018278	TN-LEADS-B	Replacement Test Leads for Terminator
	11018279	106200	Replacement Main Power Supply for Terminator


990DSL CopperPro upgrades

	SSI/PID #	VPN	Description
	700-254-468 933264	V-MODEL-SA -UGX	DSL Qualification and Analysis (Spectral Analysis) Upgrade Adds these functions to a V-MODEL-B or V-MODEL-C configurations. Field installed. Requires serial number with order.
		V-MODEL-A /B-UGK	V-MODEL-A/B to V-MODEL-C Enhancement Package Upgrades either a V-MODEL-A or V-MODEL-B configuration to a V-MODEL-C configuration. Installed at a Fluke Networks Service Center only. Does not include DSL Qualification and Analysis (Spectral Analysis) functions. Add V-MODEL-SA-UGX. Requires serial number with order.

990DSL CopperPro accessories

	SSI/PID #	VPN	Description
	700-254-469/933265	668225	Battery Pack NiMH
	700-254-470/933266	1610847	Test Leads Bed of Nails
	700-254-471/933267	1610864	Bag Storage Deluxe
	700-254-472/933268	944223	Charger Power Supply
	700-254-473/933269	284174	Power Cord AC Line
	700-254-474/910923	800695	Charger Adapter 12V Lighter
	700-254-475/933270	1576950	Strap Shoulder w/Strand Hook
	700-245-476/933271	1554870	User Manual
	700-254-477/933272	944806	Cable Serial Data
	700-254-478/933273	1312370	Gauge Wire
	700-254-479/933274	1320505	Cord RFL Strapping

635 QuickBERT-T1

	SSI/PID #	VPN	Description
	700-250-160 584481	635	635 QuickBERT- T1 Full-featured handheld T1 bit error rate test set. Features all standard patterns and loop codes. Tests DS1 and DS0 level, frequency. Monitor voice and DTMF. Emulates CSU.
	700-250-161 584482	635-1	635 QuickBERT- T1 with Cable Kit Same as above with cable kit, including two Bantam to 310 and Bantam to alligator clip cables, and one Bantam to RJ 48 cable.



Voltage Detector



SSI/PID #	VPN	Description
103-082-699	C9970	Voltage Detector (188A) Proven protection for field technicians. Prevents accidental electrical shocks in the outside plant environment. Protects against AC voltage up to 20,000 volts and DC up to 2000 volts.
572223	C9974	Voltage Detector Kit Includes Voltage Detector, probe cap, storage bag, temporary bond, ground cord and test plug.
103-551-719	C9966	Voltage Detector Test Plug
402-761-530	C9965	Voltage Detector Conductive Cap

NETWORK SUPERVISION

Fluke Networks
P.O. Box 777, Everett, WA USA 98206-0777

Fluke Networks operates in more than 50 countries worldwide. To find your local office contact details, go to www.flukenetworks.com/contact.

©2005 Fluke Corporation. All rights reserved.
Printed in U.S.A. 1/2005 2084187 F-ENG-P Rev D